



cincinnati time systems

Instructions to set a static IP Address on an NT5000III:

Press the ← twice

Press “888” then “Enter”

Press “8” the display will show “Admin Password”

Press “160419” then “Enter”

Press 2 for “set comm port

Press “7” which is “Ethernet-9600”

Press “1” to Set IP Address

Type the desired static IP Address using leading 0’s to fill any spaces and press “Enter”

Press “2” to Exit

Press “Enter” several times until the display shows the time & date again

Note: You will need to perform these functions within about 5 seconds on each selection or the display will time out and go back toward the normal display one screen at a time.

To set the Gateway address and Netmask:

With clock plugged into the same local network, using Internet Explorer type the IP Address programmed in the clock (from above steps) on the internet address line. The following utility screen should come up and allow re-programming of the Gateway and Subnet Mask (as well as the IP address) on the network settings tab.

Network Enabler Web Console - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address http://192.168.1.200/

Main Menu

- Overview
- Basic Settings
- Network Settings
- Serial Settings
- Operating Settings
- Accessible IP Settings
- Auto warning Settings
- Digital IO
- Serial Command Mode
- Change Password
- Load Factory Default
- Save/Restart

## Welcome to Network Enabler Web Console !

Model Name	NE-4100T-CMD
MAC Address	00:90:E8:0B:67:17
Serial No.	366
Firmware Version	3.3

Network Enabler Web Console - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address http://192.168.1.200/

Main Menu

- Overview
- Basic Settings
- Network Settings
- Serial Settings
- Operating Settings
- Accessible IP Settings
- Auto warning Settings
- Digital IO
- Serial Command Mode
- Change Password
- Load Factory Default
- Save/Restart

## Network Settings

IP address	<input type="text" value="192.168.1.200"/>
Netmask	<input type="text" value="255.255.255.0"/>
Gateway	<input type="text"/>
IP configuration	Static <input type="button" value="v"/>
DNS server 1	<input type="text"/>
DNS server 2	<input type="text"/>
<b>SNMP Setting</b>	
SNMP	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Community name	<input type="text" value="public"/>
Contact	<input type="text"/>
Location	<input type="text"/>
<b>IP Address report</b>	
Auto report to IP	<input type="text"/>
Auto report to TCP port	<input type="text" value="3001"/>
Auto report period	<input type="text" value="10"/> seconds
<input type="button" value="Submit"/>	